



# Tablet Management Station 16, for iPad®

## Highlights

### Safe & Secure

- Tested and certified to UL 60950-1 standards, FCC requirements and all applicable country-specific regulations
- Six-point lock assembly provides strong theft deterrence; includes security screws to attach product to the wall
- Fan and ventilation system maintains safe operating temperature
- Ergotron not only uses UL-certified components, but goes a step further to have UL certify the entire system to guarantee safe use within the classroom, healthcare, or enterprise setting

### Top-rated Sync & Charge

- Built-in syncing capability; simultaneously sync up to 10 devices by connecting your laptop via the cabinet's USB port
- Full 2.1A charging capability

### Slim & Open Design

- Fits most anywhere: very low profile – only 4" (10 cm) deep, even with access doors
- Accommodates most iPad cases – including the popular Otterbox Defender™ and Griffin Survivor™

### Easy Set-up & Operation

- Choose pre-installed 30-pin or pre-installed Lightning™ cable option
- Quick, simple installation includes mounting template
- Patent-pending Show & Stow™ technology extends iPad devices to the user when the door is opened for easy storage and removal
- Easy to clean, sleek and smart design hides device and cord clutter
- Clear ISI (Individual Status Indicator) LEDs provide power and charging status of each individual device at a glance



## Ready. Set. Charge.

Sleek, low-profile design accommodates the Apple® iPad, iPad mini and iPod® touch. Durable steel doors with robust six-point lock and key assembly provide strong theft deterrence. Full 2.1A charging capability. Tested and certified to UL 60950-1 standards.



- Compact Size: 23.2" W x 31.8" H x 4.0" D (59 x 80,9 x 10,2 cm)
- Easy installation:
  1. Mount two brackets on the wall using installation template
  2. Hang wall mount unit
  3. Secure to wall with security screws
  4. Install power cord cover
  5. Plug iPad devices into unit
  6. Plug Tablet Management Wall Mount into the wall outlet
- Includes external USB 2.0B port to connect laptop for syncing (USB cable not included)
- Cooling/ventilation: one 5V DC continuous operation fan
- Power system: input: 100-240V~, 2.0A, 50/60 Hz
- Temperature range:
  - Operating 0° to 30°C (32° to 86°F)
  - Storage -40°C to 60°C (-40° to 140°F)
- Relative humidity (maximum):
  - Operating 10–90% (non-condensing)
  - Storage 5–95% (non-condensing)
- Altitude (maximum): 2000 m (6,562 feet)
- Environmentally clean: RoHS, REACH, WEEE and EU (94/62/EC) packaging compliant
- Entire system certified to UL 60950-1 and UL 2442. Complies with FCC Part 15 Class A requirements



	For iPad	Tablet Management Wall Mount 10 For 30-Pin iPad	Tablet Management Wall Mount 10 For Lightning iPad
<b>Part #</b> (color)		(silver/black) US/CA/MX <b>DM10-1001-1</b> EU <b>DM10-1001-2</b> UK/SING/HK <b>DM10-1001-3</b> AU/NZ <b>DM10-1001-4</b> CN <b>DM10-1001-5</b> JP <b>DM10-1001-6</b>	(silver/black) US/CA/MX <b>DM10-1002-1</b> EU <b>DM10-1002-2</b> UK/SING/HK <b>DM10-1002-3</b> AU/NZ <b>DM10-1002-4</b> CN <b>DM10-1002-5</b> JP <b>DM10-1002-6</b>
<b>Cables</b>		30-pin	Lightning
<b>Charge</b>		2.1A	2.1A
<b>Compatible Devices</b> (most cases fit)		iPhone 4S, iPhone 3GS iPod touch (3rd and 4th generation) iPod touch (3rd generation) iPad, iPad2, iPad (3rd generation)	iPad Air, iPad mini with Retina Display, iPhone 5 iPod touch (5th generation) iPad mini, iPad (4th generation)
<b>UL Certification</b>		Yes	Yes
<b>Maximum Dimensions Individual Tablet</b> (including cover)		≤ 10.2"H x 7.9"W x 0.9"D (25,9 x 20,1 x 2,3 cm)	≤ 10.2"H x 7.9"W x 0.9"D (25,9 x 20,1 x 2,3 cm)
<b>Weight Capacity</b>		24 lbs (11 kg) 2.4 lbs (1,1 kg) per device	24 lbs (11 kg) 2.4 lbs (1,1 kg) per device
<b>Shipping Dimensions</b>		36.5" x 26.4" x 7.0" (92,6 x 67 x 17,7 cm)	36.5" x 26.4" x 7.0" (92,6 x 67 x 17,7 cm)
<b>Shipping Weight</b>		39.5 lb (17,9 kg)	39.5 lb (17,9 kg)
<b>Warranty</b>		Five (5) years workmanship/mechanical components, two (2) years on power module, one (1) year on electrical components	

TABLET CASES – The following iPad 2/iPad (3rd generation)/iPad (4th generation) cases are tested and confirmed to work with the Tablet Management Wall Mount: Apple iPad Smart Case, Belkin Protective Case with Stand, Belkin Tri-Fold Folio, Belkin Snap Shield, Brenthaven Bionic, Cascrowd Trifold Case, Cascrowd Omni, Griffin Intellicase, Griffin Survivor, Gumdrop Drop Tech, Hard Candy Street Skin, Logiix Roadster II, Otterbox Defender Series (without separate top cover), Otterbox Reflex Series, Speck FitFolio, STM Skinny 3, STM Grip, Targus SafePort Rugged and Rugged Max Pro, Targus Slim Case, Targus Versavu, Trident Aegis, Trident Kraken AMS

© 2014 Ergotron, Inc. rev. 10/22/2014/EA Literature made in US  
Content is subject to change without notification

**Americas Sales and Corporate Headquarters**  
St. Paul, MN USA  
(800) 888-8458  
+1-651-681-7600  
www.ergotron.com  
sales@ergotron.com

**EMEA Sales**  
Amersfoort, The Netherlands  
+31 33 45 45 600  
www.ergotron.com  
info.eu@ergotron.com

**APAC Sales**  
Tokyo, Japan  
www.ergotron.com  
apaccustomerservice@ergotron.com

**Worldwide OEM Sales**  
www.ergotron.com  
info.oem@ergotron.com

**ERGOTRON®**

**NORTEK** A Nortek Company